OMRON

Model K8AB-AS

Measuring & Monitoring Relay

English Instructions Manual

Thank you for purchasing an OMRON pridyct. In this Instructions Manual, you will find information about this product's features, capabilities, and operating instructions. Please observe the following when using this product.

- This product is designed for use by qualified electrical engi
- · Read and understand this Instructions Manual thoroughly, and make proper use of this product.
- Keep this Instructions Manual for future reference.

OMRON Corporation

product.

9419058-9 D

Precautions for Safe Use

Make sure to follow the instructions below to ensure safety.

- 1. Do not use or keep this product in the following environments
 - Outdoors, or places subject to direct sunlight or wearing weather.
 - · Places where dust, iron powder, or corrosive gases(in particular, sulfuric or ammonia gas) exist.
 - Places subject to static electricity or inductive noise · Places where water or oil come in contact with the
- 2. Make sure to install this product in the correct direction. 3. There is a remote risk of electric shock. Do not touch
- terminals while electricity is being supplied. Make sure to thoroughly understand all instructions in the Instructions Manual before handling this product.
- 5. Make sure to confirm terminal makings and polarity for
- correct wiring.
 6. Ensure that terminal screws have been tightened firmly. Recommended torque : 0.49 N \cdot m
- Assured torque: 0.59 N · m 7. Operating ambient temperature and humidity for this product must be within the indicated rating when using this product.
- 8. There is a remote risk of explosion. Do not use this product where flammable or explosive gas exists.
- 9. Make sure that no weight rests on the product after installation
- 10. To enable an operator to turn off this product easily. install switches or circuit breakers that conform to relevant requirements of IEC60947-1 and IEC60947-3. and label them appropriately.
- 11. Do not turn a setting volume beyond the scope of

Precautions for Correct Use

- For Proper Use

 1 Do not use the product in the following locations.
 Places subject to radiant heat from heat generating devices.
- devices.

 Places subject to vibrations or physical shocks.

 Make sure to use setting values appropriate for the controlled object. Failure to do so can cause unintended operation, and may result in accident or corruption of the product.
- (3) Do not use thinner or similar solvent for cleaning. Use
- commercial alcohol. (4) When discarding, properly dispose of the product as
- industrial waste.
- (5) Only use this product within a board whose structure allows no possibility for fire to escape.
 (6) This is a class A product. In residential areas it may cause radio interference, in which case the user may
- be required to take adequate measures to reduce

About Installation

- interference.

 About Installation

 (1) When wiring, use only recommended crimp terminals.

 (2) Do not block areas around the product for proper dissipation of heat. (If you do not secure space for heat dissipation, life cycle of the product will be compromised.)

 (3) To avoid electrical shocks, make sure that power is not supplied to the product while wiring.

 (4) To avoid electrical shocks, make sure that power is not supplied to the product when performing DIP switch settings.

 Noise Conutermeasures

 (1) Do not install the product near devices generating strong high frequency waves or surges.

 (2) When using a noise filter, check the voltage and current and install it as close to the product as possible.

 (3) In order to prevent inductive noise, wire the lines connected to the product separately from power lines carrying high voltages or currents. Do not wire in parallel with or on the same cable as power lines. Other measures for reducing noise include running lines along separate ducts and using shield lines.

 To avoid faulty operations, malfunctions, or failure, observe the following operating instructions,
- To avoid faulty operations, malfunctions, or failure, observe the following operating instructions.

 When turning on the power, make sure to realize rated voltage within 1 second from the time of first
- rated voltage warm is considered.

 supply of electricity.

 (2) Make sure to use power supply for operations, inputs, and transformer with the appropriate capacity and rated burden.

 (3) Maintenance and handling of this product may only
- (3) Maintenance and nandaling of this product may only be performed by qualified personnel.

 (4) Distortion ratio of input wave forms must be 30% or less. Use of this product with circuits that have large distortion in wave forms may result in unwanted operations.
- operations.
 Susing this product for thyrister controls or inverters wil result in errors.
 When setting the volume, adjust the control from the minimum side to the maximum side.

Applicable Standards ______

Installation environment	Installation Category Ⅲ, Ponllution Degree 2		
Application Standard	EN60255-5/-6		
Safety Standard	EN60664-1 UL508, CAN/CSA C22.2 No.14 (Auxiliary Devices, Current Monitoring Relay)		
	(EMI) EN61326 Industrial applications		
	Terminal interference wave voltage CISPR11 Group1, ClassA : CISPR16-1/-2 Electromagnetic interference wave CISPR11 Group1, ClassA : CISPR16-1/-2		
	(EMS) EN61326 Industrial applications		
	Electrostatic discharge	EN61000-4-2 : 4kV(Contact) 8kV(In air)	
EMC	Radiating radio- frequency electr -omagnetic field	EN61000-4-3 : 10V/m 1kHz Sine Wave Amplitude Modulation (80MHz to 1GHz)	
	Burst	EN61000-4-4 : 2kV(Power Line) 1kV(I/O Signal line)	
	Surge	EN61000-4-5 : 1kV with line (Power Line 2kV with ground (Power Line	
	Conducted RF	EN61000-4-6: 3V(0.15 to 80MHz)	
	Power frequency magnetic field immunity	EN61000-4-8 : 30A/m	
	Voltage dip/Short interruptions	EN61000-4-11 : 0.5 Cycle, 0.180° each polarity 100% (Rated Voltage)	

Overview

This product is an electric controller, which outputs an alarm, featuring current monitoring func-

■ Specifications ■

Rating

Operating power		24 VAC/DC, 100/115 VAC, 200/230 VAC	
Power consumption		24 VAC/DC : 5VA/1W max. 100/115 VAC : 4 VA max. 200/230 VAC : 5 VA max.	
Rated input	K8AB-AS1	AC/DC2-20mA/10-100mA/50-500mA	
	K8AB-AS2	AC/DC0.1-1A/0.5-5A/0.8-8A	
	K8AB-AS3	AC10-100A/20-200A (See note 1)	
Input impedance	K8AB-AS1	5 Ω max.	
	K8AB-AS2	0.2 Ω max.	
	K8AB-AS3	Use in compination with the omron K8AC-CT200L Current Transformer.	
Operating value setting range(SV)		10% to 100% of maximum rated input value.	
Hysteresls(HYS)		5% to 50% of operating value.	
Operating time(T)		0.1 to 30 s	
Operating power ON lock(LOCK)		0 to 30 s	
Output relays		One SPDT relay	
Output relays	Resistive load	6 A at 250 VAC 6 A at 30 VDC	
	Maximum switching capacity	1,500 VA	
	Minimum load	10 mA at 5 VDC	
	Electrical life	Make : 50,000 times, Break : 30,000 times	
Ambient operating temperature		-20 to 60°C (with no condensation or icing)	
		25% to 85% (with no condensation)	

Output Rating

Operating voltage range		85% to 110% of rated operating voltage
Rated power supply frequency		50/60 Hz ± 5 Hz
Input frequency	K8AB-AS1/AS2	DC or AC input (45 to 65 Hz)
	K8AB-AS3	AC input (45 to 65 Hz)
Overload resistane	K8AB-AS1/AS2	Continuous input : 120% of maximum input, 1s : 150% of maximum input.
	K8AB-AS3	Continuous input : 120% of maximum input, 30s : 200%, 1s : 600%, of maximum input.
Repeat error	Operating value	± 2% of operating value
	Onerating time	+ 50 ms. (See note)


setting.

Undercurrent: Measured when the input rapidly chamges from 120% to 0% of setting.

Installation

Diagram of Outside Dimensions

Unit: mm




Installation Procedure: Attaching to the DIN rail or attaching with front screws *Measurements for attachment with front screws



When attaching wih front screws, draw out hooks on the bottom of the product to the left and right sides.


Installation Procedure

· Pull down the hook, and then fasten the upper tab onto the rail, fitting in the unit until the hook locks into place



Uninstallation Procedure

· Using a flathead screwdriver or a similar tool, pull out the hook downward and lift the unit from the bottom.



Fixing Bracket


Attach the type K8AB to the DIN rail.

• DIN Rail Type PFP-100N (1,000mm) Type PFP-50N (500mm)

Recommended Crimp Terminal

Recommended Crimp Terminal	Recommended Cable Diameter
Al 1,5-8BK (Phoenix Contact product)	AWG#16
AI 1-8RD (Phoenix Contact product)	AWG#18
AI 0,75-8GY (Phoenix Contact product)	AWG#18


Exclusive CT K8AC-CT200L (Omron product)




Switchable with NO/NC Dip switch

SWICH	ON ● ↑ OFF○ ↓	ON OFF	3	2	1
Resetting	Automatic reset	-	-	•	
method	Manual reset	_	-	0	щ
Relay drive	Normally closed	-	•	-	USE
method	Normally open	_	0	-	NO
Operating	Undercurrent	•	-	_	
mode	Overcurrent	0	_		

■ Time Chart




Terminal Connections



Name	Terminal Name	Description
Terminals	I1, I2, I3	Current input terminals
	С	Common for voltage input terminals
	A1, A2	Operative power supply
	11	Common for terminals
	12	b-contact output
	14	a-contact output
	SV	Operate value setting (10 to 100%)
\/-\ O-#i	HYS.	Hysteresis setting (5 to 50%)
Volume Settings	Т	Operate time setting (0.1 to 30s)
	LOCK	Startup lock time setting (0 to 30s)
	PWR	Power indication : Green
LED Indications	RY	Relay output status : Yellow Light-on 11-14 conduction
	ALM	Alarm operation status : Red Light-on = Alarm output status

■ Wiring Diagram



Suitability for use

OMRON shall not be responsible conformity with any stan-dards, codes, or regulations that apply to the combination of the products in the customer's application or use of the product.

. Take all necessary steps to determine the suitability of the

product for the systems, machines, and equipment with which it will be used.

Know and observe all prohibitions of use applicable to this

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY
WITHOUT ENSURING THAT THE SYSTEM AS A
WHOLE HAS BEEN DESIGNED TO ADDRESS THE
RISKS, AND THAT THE OMRON PRODUCT IS PROPER -LY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM. See also Product catalog for Warranty and Limitation of Liability.

Contact Information

OMRON ELECTRONICS LLC.
One Commerce Drive Schaumburg, IL 60173-5302 U.S.A
Phone: 1-847-843-7900 Fax: 1-847-843-7787
OMRON CANADA INC.
885 Milner Avenue Scarborough, Ontario M1B 5V8, CANADA
Phone: 1-416-286-64645 Fax: 1-416-286-6648
OMRON EUROPE B.V.
Wegalaan 67-69, 2132 JD Hoofddorp The Netherlands
Phone: 31-23-56-81-300 Fax: 31-23-56-81-388
OMRON ELECTRONICS PTY-LTD.
71 Epping Road, North Ryde, Sydney, N.S.W 2113, Australia

71 Epping Road. North Ryde, Sydney, N.S.W 2113, Australia Phone: 61-2-9878-6377 Fax: 61:2-9878-6981 OMRON ASIA-PACIFIC PTE. LTD.
No. 438A Alexandra Road #05-05/08(Lobby 2), Alexandra Technopark, Singapore 119967 Phone: 65-6835-3011 Fax: 65-6835-2711 OMRON CORPORATION.
Shiokoji Horikawa, Shimogyo-ku, KYOTO, 600-8530 Japan Phone: 81-75-344-7109 Fax: 81-75-344-7149